



INSTALLATION

- 1) R1 AND R2 INSTALLED BETWEEN CABLE TRAY ON WEST WALL.
- 2) INSTALL R2 18" HIGHER THAN R1.
- 3) INSTALL T1 TO T4 SAME HEIGHT AS R1.
- 3) INSTALL T5 TO T8 SAME HEIGHT AS R2.

OSID POWER FACP

- CCT#1 - R1
- CCT#2 - T1 TO T4
- CCT#3 - R2
- CCT#4 - T5 TO T8

NOTES



6				PROJECT	BEAM DETECTOR	
5					GA	
4				TITLE	SAMPLE	
3						
2						
1	AA	ISSUED FOR REVIEW.	YY/MM/DD			
#	BY	DESCRIPTION	DATE	DRAWN	BB	DATE YYYY/MM/DD
				CHKD	CC	CONTRACT # N/A
	PHONE					
	OFFICE			SCALE	NTS	DWG. # 1 of 1